


PROGRAMMING MENU For FUJI VENDING MACHINE



Remote Display	Contents	Data Range	
C A R D	6-03	Check and set ID card month of issued	1-12 month
	6-04	Check and set ID card year of issued	50-49 (1950-2049)
	6-05	Check and set validity of ID card number	101-110
	6-06	Check and set ID card number by invalid department	1-110
	6-07	Check and set valid time for selection button	0-255 seconds
	6-11	Check and delete sales quantity by cash group	0-999,999 pieces
	6-12	Check and delete sales quantity by non-cash group	0-999,999 pieces
	6-13	Check and delete sales amount by cash group	0-999,990 Yen
	6-14	Check and delete sales amount by non-cash group	0-999,990 Yen
	6-15	Check and delete sales quantity by cash price	0-999,999 pieces
	6-16	Check and delete sales quantity by non-cash price	0-999,999 pieces
	6-17	Check and delete sales amount by cash price	0-999,990 Yen
	6-18	Check and delete sales amount by non-cash price	0-999,990 Yen